

1.3 hp, 5" & 6" Dynalocke® Head Sanders

Air Tool Manual – Safety, Operation and Maintenance

SAVE THIS DOCUMENT, EDUCATE ALL PERSONNEL

Model	RPM	Pad Size	Pad Style	Spindle
52760	12,000	5"	Hook-Face	5/8"-11
52761	12,000	6"	Hook-Face	M14 x 2
52762	12,000	6"	Hook-Face	5/8"-11



FIND THE MOST CURRENT OFFERING OF SUPPORT DOCUMENTS AND ACCESSORIES @ WWW.DYNABRADE.COM

! WARNING

Read and understand this tool manual before operating your air tool. Follow all safety rules for the protection of operating personnel as well as adjacent areas. Always operate, inspect and maintain this tool in accordance with the American National Standards Institute (ANSI) Safety Code for Portable Air Tools – B186.1. For additional safety information, refer to Safety Requirements for the Use, Care and Protection of Abrasive Wheels – ANSI B7.1, Code of Federal Regulation – CFR 29 Part 1910, European Committee for Standards (EN) Hand Held Non-Electric Power Tools – Safety Requirements and applicable State and Local Regulations.

SAFETY LEGEND

	! WARNING Read and understand tool manual before work starts to reduce risk of injury to operator, visitors, and tool.	! WARNING Practice safety requirements. Work alert, have proper attire, and do not operate tools under the influence of alcohol or drugs.	
	! WARNING Eye protection must be worn at all times, eye protection to conform to ANSI Z87.1.	! WARNING Ear protection to be worn when exposure to sound, exceeds the limits of applicable Federal, State or local statutes, ordinances and/or regulations.	
	! WARNING Respiratory protection to be used when exposed to contaminants that exceed the applicable threshold limit values required by law.	! WARNING Air line hazard, pressurized supply lines and flexible hoses can cause serious injury. Do not use damaged, frayed or deteriorated air hoses and fittings.	

! WARNING

Some dust created by grinding, sanding, drilling, and other construction activities contain chemicals known to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints
- Crystalline silica from bricks and cement and other masonry products
- Arsenic and chromium from chemically treated lumber

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

SAFETY INSTRUCTIONS

Carefully Read all instructions before operating or servicing any Dynabrade® Abrasive Power Tool.

Products offered by Dynabrade are not to be modified, converted or otherwise altered from the original design.

Tool Intent: 5" & 6" Dynalocke® Head Sanders are ideal for material removal and surface preparation using abrasive discs with appropriate back-up pads.

Do Not Use Tool For Anything Other Than Its Intended Applications.

This power tool is not intended for use in potentially explosive atmospheres and is not insulated against contact with electrical power.

Training: Proper care, maintenance, and storage of your air tools will maximize their performance.

- Employer's Responsibility – Provide 5" & 6" Dynalocke® Head Sanders operators with safety instructions and training for safe use of tools and accessories.

Accessory Selection:

- **Warning:** DO NOT use cut-off wheels, saw blades, grinding wheels or flap discs. See tool intent for recommended accessory.
- Follow tool specifications before choosing size and type of accessory.
- Back-up Pad/Abrasive RPM (speed) rating MUST be approved for AT LEAST the tool RPM rating.
- Only use recommended fittings and air line sizes. Air supply hoses and air hose accessories must have a minimum working pressure of 150 PSIG (10 Bars, g) or 150 percent of the maximum pressure produced in the system, whichever is higher. (See Machine Specifications table on back cover.)

(continued on next page)

OPERATING INSTRUCTIONS

Warning: Always wear eye protection. Operator of tool is responsible for following: accepted eye, face, respiratory, hearing and body protection.

Caution: Hand, wrist and arm injury may result from repetitive work, motion and overexposure to vibration. Vibration level was established using ISO 8662-8.

5" Models: Vibration level (m/s²): 3.38 with a 100 gram back-up pad attached. 6" Models: Vibration level (m/s²): 3.55 with a 125 gram back-up pad attached.


Warning: Be sure that any loose clothing, hair and all jewelry is properly restrained.

- Keep hand and clothing away from working end of the air tool which has a potential hazard of cutting and severing.
- Secure inlet bushing on air tool with a wrench before attempting to install the air fitting to avoid damaging housing assembly.
- BEFORE MOUNTING DYNALOCKE® SANDING HEAD ASSEMBLY, after all tool repairs and whenever a sander is issued for use, check tool RPM (speed) with tachometer with air pressure set at 90 PSIG while the tool is running. If tool is operating at a higher speed than the RPM marked on the tool housing, or operating improperly, the tool must be serviced and corrected before use.

Warning: Back-up pad speed rating must be approved for at least the tool RPM rating. Check accessory manufacturer for details on maximum operating speed or special mounting instructions.

Back-Up Pad/Abrasive Mounting

- Disconnect air source from the tool.
- Clean Stud Washer and Dynalocke® Sanding Head mounting surfaces. Inspect for nicks, cuts, sharp edges, and thread wear.
- Install back-up pad onto Dynalocke Sanding Head with stud secured. Stud should be fully threaded into Dynalocke® Sanding Head.
- Tighten stud of pad onto Dynalocke® Sanding Head.
- Check mounting by rotating spindle, make certain abrasive disc is concentrically mounted and back-up pad is not excessively warped.



- Connect tool to air source. Be careful NOT to depress throttle lever in the process. **Do not expose air tool to inlet pressure above 90 PSIG or (6.2 Bars).**

Warning: After installing the back-up pad/abrasive, make sure that no one is in the unguarded plane before starting the sander. IN A PROTECTED AREA, test run the sander at a reduced speed to check for good balance. Gradually increase tool speed. DO NOT USE if tool vibration is excessive. Correct cause, and retest to insure safe operation. Test sander at its free speed (RPM) in a protected area for at least one minute before use.

Warning: Use only appropriately sized abrasive sanding discs properly secured and centered to the backing pads provided with the air sander.

- Release throttle lever when air supply is interrupted.
- DO NOT engage spindle lock while spindle is rotating.
- Make sure that work area is uncluttered, and visitors are at a safe range from the tools and debris.
- Air tools are not intended for use in explosive atmospheres and are not insulated for contact with electric power sources.
- Use a vise or clamping device to hold work piece firmly in place.
- Do not apply excessive force on tool or apply "rough" treatment to it.
- Always work with a firm footing, posture and proper lighting.
- Ensure that sparks and debris resulting from work does not create a hazard.
- Always be aware of bystanders in work areas.
- This tool has side exhaust, rotate muffler cover by hand to desired exhaust direction. Exhaust may contain lubricants, vane material, bearing grease, and other materials flushed through the tool.

Warning: Sanding certain materials can create explosive dust. It is the employers responsibility to notify the user of acceptable dust levels.

- Always use dust extraction or suppression systems and personal protective equipment which are suitable for the materials being processed.
- Sanding can cause sparks which can cause fires or explosions. It is the users responsibility to make sure the work area is free of flammable materials.
- Use side handle provided to best control tool during sanding.


Report to your supervisor any condition of the tool, accessories, or operation you consider unsafe.

Air System

LUBRICATOR SETTING

1 DROP/MIN.

20 SCFM



- Check all connections and air hoses for good condition and proper installation.
- Dynabrade Air Power Tools are designed to operate at 90 PSIG (6.2 Bar/620 kPa) maximum air pressure at the tool inlet, when the tool is running. Use recommended regulator to control air pressure.
- Ideally the air supply should be free from moisture. To facilitate removing moisture from air supply, the installation of a refrigerated air dryer after the compressor and the use of drain valves at each tool station.

Maintenance Instructions

Important: To keep tools safe a Preventative Maintenance Program is required whenever portable power tools are used. The program shall include inspection of air supply lines, air line pressure, proper lubrication and repair of tools. Refer to ANSI B186.1 and EN 792 for additional maintenance information.

- Use only genuine Dynabrade replacement parts to insure quality. To order replacement parts, specify **Model#**, **Serial#** and **RPM** of your air tool.
- It is strongly recommended that all Dynabrade rotary vane air tools be used with a Filter-Regulator-Lubricator to minimize the possibility of misuse due to unclean air, wet air or insufficient lubrication. Dynabrade recommends the following: **10681** Air Line Filter-Regulator-Lubricator — Provides accurate air pressure regulation, two-stage filtration of water contaminants and micro-mist lubrication of pneumatic components. Operates up to 55 SCFM @ 100 PSIG has 1/2" NPT female ports.
- **Lubricate wick system through the angle gear oil fitting with 2-3 plunges for every 24 hours of use, to achieve maximum gear life.**
Important: Use only the recommended angle gear oil for the wick system. Do not contaminate the wick with any other oil or grease product. (Order **95848** Gear Oil and **95541** Gun) Always prime pump to ensure good flow before lubricating gears.
- Dynabrade recommends one drop of air lube per minute for each 20 SCFM (example: if the tool specification states 40 SCFM, set the drip rate on the filter-lubricator to 2 drops per minute). Dynabrade Air Lube (P/N **95842**: 1 pt 473 ml) is recommended.

Routine Preventative Maintenance:

- Check free speed of tool using a tachometer without Dynalocke® Sanding Head Assembly attached with 90 PSIG at inlet while tool is running. This governor controlled tool should be speed checked every 20 hours of use or weekly, whichever occurs more frequently. Always check tool speed after any maintenance or repair.
- Take special care when performing any maintenance to the governor, the governor is preset at the factory to maintain the maximum rated speed for the tool, if any inconsistency is found in the operating speed the tool must not be used and must be further tested.
- Inspect pad backing for excessive wear, nicks, cracks and cuts at the pad edges. Do not use pads that show excessive wear. Check pad backing for concentricity.
- Visually inspect abrasive discs for nicks, cuts, tears at the edges. Abrasive disc with a curved shape indicates improper storage. Do not use abrasives that show these characteristics.

-
- Mineral spirits are recommended when cleaning the tool and parts. Do not clean tool or parts with any solvents or oils containing acids, esters, ketones, chlorinated hydrocarbons or nitro carbons.
 - **DO NOT** clean or maintain tools with chemicals that have a low flash point (example: WD-40®).
 - A Motor Tune-Up Kit (P/N **96100**) is available which includes high wear and medium wear motor parts.
 - Air tool labels must be kept legible at all times, if not, reorder label(s) and replace. User is responsible for maintaining specification information i.e.: Model #, S/N, and RPM. (See Assembly Breakdown)
 - Blow air supply hose out prior to initial use.
 - Visually inspect air hoses and fittings for frays, visible damage and signs of deterioration. Replace damaged or worn components.
 - Refer to Dynabrade's Warning/Safety Operating Instructions Tag (Reorder No. **95903**) for safety information.

After maintenance is performed on tool, add a few drops of Dynabrade Air Lube (P/N **95842**) to the air line and start the tool a few times to lubricate air motor. Check for tool vibration before mounting abrasive wheel accessory.

Handling and Storage:

- Use of tool rests, hangers and/or balancers is recommended.
- Protect tool inlet from debris (see Notice below).
- **DO NOT** carry tool by air hose. When carrying tool keep hands away from throttle lever to avoid accidental startup.
- Protect abrasives accessories from exposure to water, solvents, high humidity, freezing temperature and extreme temperature changes.
- Store abrasive discs prior to use at 40-50% relative humidity and 60-80° F (15-27° C) to reduce curling.
- Store accessories in protective racks or compartments to prevent damage.

Notice

All Dynabrade motors use the highest quality parts and metals available and are machined to exacting tolerances. The failure of quality pneumatic motors can most often be traced to an unclean air supply or the lack of lubrication. Air pressure easily forces dirt or water contained in the air supply into motor bearings causing early failure. It often scores the cylinder walls and the rotor blades resulting in limited efficiency and power. Our warranty obligation is contingent upon proper use of our tools and cannot apply to equipment which has been subjected to misuse such as unclean air, wet air or a lack of lubrication during the use of this tool.

Lifetime Warranty


All Dynabrade portable pneumatic power tools are rigorously inspected and performance tested in our factory before shipping to our customers. If a Dynabrade tool develops a performance problem and an inherent defect is found during normal use and service, Dynabrade will warrant this tool against defects in workmanship and materials for the lifetime of the tool. Upon examination and review at our factory, Dynabrade shall confirm that the tool qualifies for warranty status, and will repair or replace the tool at no charge to the customer. Normally wearable parts and products are NOT covered under this warranty. Uncovered items include bearings, contact wheels, rotor blades, regulators, valve stems, levers, shrouds, guards, O-rings, seals, gaskets and other wearable parts. Dynabrade's warranty policy is contingent upon proper use of our tools in accordance with factory recommendations, instructions and safety practices. It shall not apply to equipment that has been subjected to misuse, negligence, accident or tampering in any way so as to affect its normal performance. To activate lifetime warranty, customer must register each tool at www.dynabrade.com. Dynabrade will not honor lifetime warranty on unregistered tools. A one-year warranty will be honored on all unregistered portable pneumatic power tools. Lifetime warranty applies only to portable pneumatic tools manufactured by Dynabrade, Inc. in the USA. Lifetime warranty applies only to the original tool owner; warranty is non-transferable.

Index Key

No.	Part #	Description
1	25265	Retainer
2	53609	Felt Seal
3	25271	Spindle - 5/8" - 11
	25269	Spindle - M14 x 2
4	01036	Bearing
5	98288	Shim (as required)
6	98287	Shim (as required)
7	25230	Bevel Gear Set
8	25264	Wick
9	02057	Bearing
10	98243	Wave Spring
11	25273	Plunger Assembly (Inclcd 97156 Ring)
12	98285	Spring
13	Housing Assembly (Includes: 01041 Gear Oil Fitting, 25275 Bushing)	
	25260	Model - 52760
	25323	Model - 52761
	25324	Model - 52762
14	25283	Silencer
15	25217	Muffler Assembly
16	98282	O-Ring (2mm)
17	98281	O-Ring (2.4mm)
18	25282	Silencer
19	25278	Muffler Cover
20	25281	Muffler Stem Assembly
21	53134	Vibration Dampening Handle
22	01007	Bearing
23	01294	Shim (as required)
24	01293	Shim (as required)
25	98242	O-Ring
26	25236	Front Bearing Plate
27	01010	Spacer
28	25233	Rotor
29	25234	Vane (4/Pkg.)
30	25235	Cylinder
31	96441	Pin
32	25237	Rear Bearing Plate
33	01206	Bearing
34	98279	Pin (2)
35	25290	Governor Cage
36	25291	Governor Weight (2)
37	25293	Governor Valve
38	25294	Governor Spring
39	25298	Shim (.25 mm Thk.) (as Req.)
40	25299	Shim (.13 mm Thk.) (as Req.)
41	25292	Governor Spindle
42	25295	Pin
43	66435	O-Ring
44	25256	Governor Housing
45	25257	Cup Nut
46	12132	Pin
47	01462	Safety-Lock Lever
48	25247	Valve Stem Assembly (Inclcd 96443 O-Ring)
49	25245	Throttle Handle (Inclcd 25246 Bushing)
50	51945	Valve Seat
51	25249	Tip Valve
52	25250	Spring
53	96442	O-Ring
54	51940	Spacer
55	25213	Inlet Bushing (Inclcd 51938 Screen (2))
56	25253	Insulating Cover
57	61326	Bolt
58	61325	Rotary Switch
59	96027	Screw - 5" Models (2)
	97099	Screw - 6" Models (2)
60	61322	Housing - Model 52760
	61266	Housing - Model 52761
	61323	Housing - Model 52762
61	61328	Counterweight - 5 in.
	61338	Counterweight - 6 in.
62	61329	Screw
63	61396	Pin
64	61397	Spring
65	61393	Pin
66	61395	Spring
67	61398	Locking Pin Bushing
68	61327	Counterweight - 5 in.
	61337	Counterweight - 6 in.
69	56052	Bearing
70	59084	V-Seal
71	61324	Balancer Shaft
72	54325	5 in. Pad - Hook-Face
	54327	6 in. Pad - Hook-Face

Right Angle Dynalocke® Head Sander Complete Assembly

25217 Muffler Assembly



KEY

O Oil: O₁ = Air Lube


W Wicking: W₁ = Gear Oil

A Adhesive: A₁ = Loctite #609
A₃ = Loctite #242
A₆ = Loctite #380
A₈ = Loctite #567
A₁₀ = Loctite #243

T Torque: N·m x 8.85 = In. - lbs.

Label Key

Part #	Description
25285	S/N, RPM Label
25287	Sanding Label



Disassembly/Assembly Instructions - Right Angle Sanders

Important: The Manufacturing Warranty is void if the tool is disassembled before the warranty expires by anyone other than a Dynabrade® Approved Repair Technician.
Notice: A 96100 Motor Tune-Up Kit is available. Also, the special repair tooling referred to in these instructions can be ordered through your Dynabrade® Distributor. Please refer to this tool manual for correct part number identification.

Important: Always follow these steps before servicing any part of this air tool.

1. Shut off the air supply, and depress throttle lever to dissipate the remaining air. Carefully disconnect the tool from the air supply hose.
Note: Use a wrench to hold the air tool inlet bushing stationary when removing the air supply connection.
2. Remove any abrasive product, flanging, guard, and side handle.

Motor Disassembly:

1. Use a 3mm drive punch to remove the throttle lever.
2. Roll back front edge of 25253 Insulating Cover just enough to expose wrench flats on 25257 Cup Nut.
3. Place padding around the housing and carefully hold the housing stationary in a vise. Use an adjustable wrench or 98283 Open End Wrench (**sold separately**) to loosen the 25257 Cup Nut. Turn counterclockwise. **Note:** Applying heat to cup nut will help loosen adhesive.
4. Carefully pull motor assembly out of the housing.
5. Hold pinion gear in a vise with aluminum or bronze jaws. Use an adjustable wrench or 95281 Open End Wrench (**sold separately**) to remove the governor assembly. **LEFT HAND THREAD** Turn clockwise.
6. Fasten 96346 2" Bearing Separator around the portion of 25235 Cylinder that is closest to 25237 Rear Bearing Plate. Place the bearing separator motor on the table of the 96232 #2 Arbor Press with pinion gear pointing downward. Use a 3/16" or 4mm diameter flat end drive punch push rotor out of the 01206 Bearing.
7. Remove the vanes from rotor and 01206 Bearing from bearing plate.
8. Fasten the vane slot portion of rotor in a vise with aluminum or bronze jaws so that the pinion gear is pointing up.
9. Use a hook/pin spanner wrench unthread pinion gear from rotor. Turn counterclockwise.
10. Remove the front bearing plate, shims and 01010 Spacer.

Motor Disassembly Complete.

Spindle/Gear Disassembly:

1. Place padding around the housing and carefully hold the housing stationary in a vise with the spindle pointing up. Use the 97782 Pin Wrench (**sold separately**) or an adjustable pin wrench to remove 25265 Retainer. **LEFT HAND THREAD** Turn clockwise.
2. Remove 53609 Felt Seal from spindle or retainer.
3. Pull spindle and gear assembly out of the housing.
4. Fasten the 96346 2" Bearing Separator under 02057 Bearing and press spindle through bearing. Remove 25264 Wick. Remove 98243 Wave Spring from the right angle housing.
5. Fasten the 96346 2" Bearing Separator between 01036 Bearing and spiral bevel gear. Place the bearing separator along with the spiral bevel gear assembly on the table of the 96232 #2 Arbor Press so that the spindle thread is pointing down. Push the gear off the spindle.
6. Remove the 01036 Bearing the same way.
7. Remove the housing from vise.

Spindle Disassembly Complete.

Spindle Lock Disassembly:

1. Apply a small amount of the Dynabrade Air Lube 10W/NR (P/N 95842 or equivalent) around the 25273 Plunger Assembly.
2. Place padding around the housing and carefully hold the housing stationary in a vise with the plunger assembly facing up.
3. Use two flat blade screwdrivers to pry the plunger assembly out of the 25275 Spindle Lock Bushing.
4. Remove the 98285 Spring and the 97156 Ring from the plunger.

Spindle Lock Disassembly Complete.

Valve Disassembly:

1. Secure 25245 Throttle Handle in a vise using wrench flats so that the 25213 Inlet Bushing pointing upward.
2. Use an adjustable wrench, unthread 25213 Inlet Bushing. Turn counterclockwise.
3. Use needle nose pliers, pull 25249 Tip Valve from handle.
4. Use a small screwdriver to remove the 96443 O-Ring from the valve stem and remove the valve stem.
5. Position 25245 Throttle Handle in the vise with 25257 Cup Nut and 25256 Governor Housing pointing up. Use a 10 mm hex key to remove the 25256 and 25257. Turn counterclockwise. **Note:** Applying heat to throttle handle will help loosen adhesive bond.
6. Push the 51945 Valve Seat out of the 25245 Throttle Handle.

Valve Body Disassembly Complete.

Locking Random Orbital Sanding Head Disassembly:

1. Lock Head Assembly in Orbital mode.
2. Secure flats on Head Assembly with 95823 21mm Open End Wrench.
3. Rotate pad counter-clockwise, removing pad from Head Assembly.
4. Engage Plunger on tool to lock spindle.
5. Turn wrench counter-clockwise to remove Head Assembly from tool.
6. Disassemble the balancer assembly as follows:
 - a. Screw the threaded portion of the 56056 Bearing Puller into the 61324 Balancer Shaft and heat the outside of the motor shaft balancer to approximately 200° F/93° C (approximately 10 seconds with a propane torch). Now, using the slider weight, pull the assembly out.
 - b. Place 96345 15/16" Bearing Separator between 56052 Bearing and 61324 Balancer Shaft.
 - c. Using 96214 Bearing Removal Tool and 96232 Arbor Press, press Balancer Shaft from Bearing and discard 59084 V-Seal.
7. If during step 6, the 56052 Bearing remains on the motor shaft balancer, it can be removed by heating the shaft balancer again and using either an inside bearing puller or a blind hole bearing puller.
8. Use 95252 2.5mm Hex Key to remove 61326 Shoulder Bolt and 61325 Rotary Switch.
9. Remove 61396 Locking Pin Insert and 61397 Spring.
10. Use a HOT AIR GUN to apply heat to 61398 Locking Pin Bushing.
11. Use 96364 Large Slotted Screwdriver to remove 61398 Locking Pin Bushing.
12. Remove 61395 Switch Spring and 61393 Pin.

Locking Random Orbital Sanding Head Disassembly is complete.

Important: Clean and inspect all parts for wear before assembling. Note: Follow all lubricant, adhesive, and torque specifications.

Valve Assembly:

1. Install 96443 O-Ring onto 25247 Valve Stem. Apply Dynabrade Air Lube to 96443 O-Ring and carefully install the valve stem and o-ring assembly into the throttle handle. **Note:** Rotating the valve stem while inserting prevents damage to the o-ring
2. Apply several drops of the Dynabrade Air Lube 10W/NR (P/N 95842 or equivalent) to valve seat pocket wall on the inside of the 25245 Throttle Handle before inserting the 51945 Valve Seat. Install the 51945 Valve Seat by aligning the 3 male prongs of the valve seat with three slots of the valve seat pocket in the throttle handle. **Note:** Use an arbor press and the 96241 Bearing Press Tool to support the valve seat and press it into the valve seat pocket. Make certain that the valve seat lays flat.

(continued on next page)

- Use needle nose pliers install **25249** Tip Valve into the throttle handle.
- Install **51940** Spacer onto **25213** Inlet Bushing, followed by the **96442** O-Ring. Install the larger end of the **25250** Spring into the inlet bushing. The smaller end of the spring fits against the back of the tip valve.
- Apply a small amount of the Loctite® #243 (or equivalent) to the external threads of the **25213** Inlet Bushing and install it onto the throttle handle. Secure throttle handle in a vise using wrench flats. (Torque to 35N-m/310 lbs. in.)
- Position the throttle handle in vise with the inlet bushing pointing downward.
- Install the **66435** O-Ring onto the **25256** Governor Housing. Apply some Dynabrade Air Lube to the o-ring. Insert the governor housing through the **25257** Cup Nut. Apply a small amount of the Loctite® #567 (or equivalent) to the external threads of the governor housing. Use a 10 mm hex key to fasten the governor housing and cup nut onto the throttle handle. Turn clockwise. (Torque to 34N-m/300 lbs. in.) **Note:** The position of the throttle lever can be adjusted to any 360° location.
- Apply a few drops of Loctite® #380 (or equivalent) to both sides of the throttle handle (as shown). Install the **25253** Insulating Cover and the **01462** Throttle Lever onto the throttle handle.

Valve Assembly Complete.

Spindle Lock Assembly:

- Install a new **97156** Ring onto the plunger and apply a small amount of the Dynabrade Air Lube 10W/NR (P/N **95842** or equivalent) to the o-ring and plunger.
- Install **98285** Spring onto the housing bushing and insert the **25273** Plunger Assembly through the spring.
- Install the plunger assembly into the spindle lock bushing. **Note:** Rotating the plunger while inserting prevents damage to the o-ring.

Spindle Lock Assembly Complete.

Motor Assembly:

- Install **01010** Spacer onto the rotor front mandrel.
- Select .003" (.08mm) thickness shims from the **01121** Shim Pack and install these into the **25236** Front Bearing Plate.
- Install **98242** O-Ring into front bearing plate groove and install **01007** Bearing, into the front bearing plate.
- Position the rotor in a vise with aluminum or bronze jaws so that the rotor spindle is pointing up. Install the front bearing/plate onto the rotor.
- Apply a small amount of the Loctite® #243 (or equivalent) to the external threads on the rotor stem and install the pinion gear. (Torque to 17N-m/150 lbs. in.) Using a hook/pin spanner wrench. Remove the assembly from the vise.
- Use a .001" (0.3mm) thick feeler gauge to check the clearance between the front bearing plate and the face of the rotor. The clearance should be .001"-.0015" (0.3-0.4mm). **Note:** If the clearance needs adjustment repeat steps 2-6 adding or removing shims as required.
- Lubricate **25234** Vanes (4) with the **95842** Dynabrade Air Lube 10W/NR (or equivalent) and install these into the rotor.
- Install **25235** Cylinder over the rotor so that the air inlet opening of the cylinder will line up with the air inlet opening on the **25237** Rear Bearing Plate.
- Install **01206** Bearing into **25237** Rear Bearing Plate.
- Use the raised inner diameter of **96244** Bearing Press Tool and the arbor press to install the rear bearing plate onto the rotor. **Note:** Carefully press the bearing/plate down until it just touches the cylinder. This will establish a snug fit between the bearing plates and the cylinder.
- Fasten the pinion gear in a vise with aluminum or bronze jaws so that the rear bearing/plate pointing up.
- Apply a small amount of the Loctite® #567 (or equivalent) to the external threads of governor assembly. Install it onto the rotor using an 19 mm crowfoot and torque wrench. **LEFT HAND THREAD** Turn counterclockwise. (Torque to 9N-m/80 lbs. in.)
- Carefully slide the motor assembly into the housing.
- Place padding around the housing and carefully hold the housing stationary in a vise. Apply a small amount of the Loctite® #567 (or equivalent) to housing external threads. Use an adjustable wrench tighten **25257** Cup Nut onto housing. Turn clockwise. (Torque to 30N-m/265 lbs. in.)

Important: Allow 30 minutes for the adhesives to cure before operating the tool.

Run the tool to make sure that the air motor is functioning properly before installing the right angle gears. Motor Assembly Complete.

Spindle/Gear Assembly:

- Position the spindle in the arbor press so that the threaded end is pointing down.
- Use a 19/32" deep well socket as a press tool, install the **01036** Bearing onto the spindle and against the step.
- Use a 19/32" deep well socket as a press tool and install the **25241** Bevel Pinion onto the spindle.
- Prepare the **25264** Wick by soaking in **95848** Gear Oil and then install the wick onto the spindle.
- Press **02057** Bearing using **96243** Press Tool (**sold separately**) onto spindle until the spindle is flush with the bearing top.
- Place padding around the housing and carefully hold the housing stationary in a vise with the right angle spindle opening facing up.

Important: Follow these steps to adjust the fit or "backlash" of the spiral bevel gear/pinion gear.

- Install the spindle assembly into the housing align wick shape to housing contour. Mesh bevel and pinion gears together.
- Apply a small amount of downward force on the spindle and rotate the spindle 360°. The rotation should be smooth without any tight feel or binding of the gear teeth. Next, rotate the spindle forward and backward to check the amount of backlash (free movement between the gear teeth). The correct fit should be minimal backlash without any binding of the gear teeth. Add or remove shims to adjust the gear "backlash".
- Place the **53609** Felt Seal into the **25265** Retainer recess bore.
- Apply a small amount of the Loctite® #567 (or equivalent) to the threads of the retainer and use the **97782** Pin wrench to install the retainer onto the housing. **LEFT HAND THREAD** Turn counterclockwise. (Torque to 23N-m/203 lbs. in.)
- Re-check the fit of the gears by hand before connecting the tool to the air supply. The correct fit should be minimal backlash without any binding of the gear teeth. Add or remove shims to adjust the gear fit if necessary.
- Use the **95541** Lubricant Gun to apply the **95848** Gear Oil Lubricant required for the lubricating wick prime the plunger before adding gear oil to housing. Inject three full plunges of the gear oil into the **01041** Gear Oil Fitting on the front of housing. **Note:** Inject three full plunges of gear oil into the lubricant fitting after operating the tool every 24-hour interval of use.

Right Angle Assembly Complete:

Muffler Assembly:

- Install **25282** Silencer (Cross section size: 7.5 mm) up and inside recess diameter of **25278** Muffler Cover.
- Install the **98281** O-Ring (Cross section size: 2.4 mm) into the inside groove of the muffler cover.
- Install the **98282** O-Ring (Cross section size: 2.0 mm) into the outside groove of the muffler cover.
- Install **25278** Muffler Cover (the side with the smaller hole) onto **25281** Muffler Stem Assembly.
- Install **25283** Silencer (Cross section size: 13 mm) into housing cavity.
- Apply a small amount of the Loctite® #243 (or equivalent) to the external threads of the **25281** Muffler Stem Assembly. Install the **25217** Muffler Assembly onto the housing. Rotate **25281** Muffler Stem Assembly until slot aligns with housing raised boss. Thread socket head cap screw into housing using a 5/32" hex key (Torque to 7N-m/60 lbs. in.).

Muffler Assembly Complete.

Locking Random Orbital Sanding Head Assembly:

- Insert **61393** Pin into **61395** Switch Spring and then place into **61322** Housing.
- Apply a small amount of Loctite® 567 (or equivalent) to the external threads of **61398** Locking Pin Bushing.
- Thread bushing into Housing with screw driver slot visible. Use **96364** Large Slotted Screwdriver to tighten bushing until it is fully seated.
- Place **61397** Spring into **61393** Pin.
- Place **61396** Locking Pin Insert in **61393** Pin and on top of **61397** Spring.
- Apply a small amount of Loctite® 242 (or equivalent) to the external threads of **61326** Shoulder Bolt.
- Place **61325** Rotary Switch on top of **61396** thread **61326** through hole in **61325** into Housing.
- Use **95252** 2.5mm Hex Key to tighten **61326** Shoulder Bolt.

(continued on page 8.)


Preventative Maintenance Schedule

For Model All 5" & 6" Dynalocke® Head Sanders

This service chart is published as a guide to expectant life of component parts. The replacement levels are based on average tool usage over one year. Dynabrade Inc. considers one year usage to be 1,000 hours.

Parts Common to all Models:

LEGEND	
T	Included in Tune-Up Kit
X	Type of wear, no other comments apply.
L	Easily lost. Care during assembly/disassembly.
D	Easily damaged during assembly/disassembly.
R	Replace each time tool is disassembled.



96100 – Motor Tune-Up Kit

Index #	Part Number	Description	Number Required	High Wear 100%	Medium Wear 70%	Low Wear 30%	Non-Wear 10%
1	25265	Retainer	1				X
2	53609	Felt Seal	1		X		
3	See Note	Spindle	1				X
4	01036	Bearing	1		X		
5	98288	Shim	1		X		
6	98287	Shim	1		X		
7	25230	Bevel Gear Set	1			X	
8	25264	Wick	1		X		
9	02057	Bearing	1		X		
10	98243	Wave Spring	1			X	
11	25273	Plunger Assembly	1			X	
12	98285	Spring	1				X
13	See Note	Housing	1				X
14	25283	Silencer	1		T		
15	25217	Muffler Assembly	1				X
16	98282	O-Ring	1		X		
17	98281	O-Ring	1		X		
18	25282	Silencer	1		T		
19	25278	Muffler Cover	1				X
20	25281	Muffler Stem Assembly	1				X
21	53134	Vibration Dampening Handle	1				X
22	01007	Bearing	1		T		
23	01294	Shim	1		T		
24	01293	Shim	1		T		
25	98242	O-Ring	1		T		
26	25236	Front Bearing Plate	1		X		
27	01010	Spacer	1			X	
28	25233	Rotor	1				X
29	25234	Vane (4/Pkg.)	1	T			
30	25235	Cylinder	1			X	
31	96411	Pin	1				X
32	25237	Rear Bearing Plate	1			X	
33	01206	Bearing	1		T		
34	98279	Pin	2		X		
35	25290	Governor Cage	1			X	
36	25291	Governor Weight	2			X	
37	25293	Governor Valve	1			X	
38	25294	Governor Spring	1			X	
39	25298	Shim	1			X	
40	25299	Shim	1			X	
41	25292	Governor Spindle	1			X	
42	25295	Pin	1			X	
43	66435	O-Ring	1			T	
44	25256	Governor Housing	1			X	
45	25257	Cup Nut	1			X	
46	12132	Pin	1		T		
47	01462	Safety-Lock Lever	1			X	
48	25247	Valve Stem Assembly	1		T		
49	25245	Throttle Handle	1			X	
50	51945	Valve Seat	1			X	
51	25249	Tip Valve	1			T	
52	25250	Spring	1			T	
53	96442	O-Ring	1		T		
54	51940	Spacer	1			X	
55	25213	Inlet Bushing	1			X	
56	25253	Insulating Cover	1			X	
57	61326	Bolt	1				X
58	61325	Rotary Switch	1				X
59	96027	Screw	2				X
60	61322	Housing	1				X
61	61328	Counterweight	1				X
62	61329	Screw	1				X
63	61396	Pin	1			X	
64	61397	Spring	1				X
65	61393	Pin	1				X
66	61395	Spring	1				X
67	61398	Locking Pin Bushing	1			X	
68	61327	Counterweight	1				X
69	56052	Bearing	1		X		
70	59084	V-Seal	1		X		
71	61324	Balancer Shaft	1				X
72	See Note	Pad	1				X

Note: Please refer to page 4 for specific part number and description.

9. Place **59084** V-Seal onto shaft of **61324** Pad Balancer Shaft.
10. Apply a small amount of Loctite® 609 (or equivalent) to the shaft of **61324**.
11. Use **57091** Bearing Press Tool and Arbor Press to press **56052** Bearing onto **61324**.
12. Apply a small amount of Loctite® 609 (or equivalent) to the outside diameter of **56052**.
13. Use an arbor press to press Balancer Shaft Assembly into Housing until fully seated.
14. Lock Head Assembly in Orbital mode.
15. Engage Plunger on tool to lock spindle and thread Head Assembly onto tool, with the Plunger still engaged use **95823** 21mm Open End Wrench to tighten Head Assembly.
16. Replace Pad.

Locking Random Orbital Sanding Head Assembly is complete.

Final Assembly:

Important: Allow 30 minutes for the adhesives to cure before operating the tool. Install and properly position all guarding and auxiliary side handle. Before installing mounting flanges or any abrasive product, the air tool must be tested for proper operation. Follow these steps to verify the correct rated operating speed of the tool.

1. Supply 3 drops of **95482** Dynabrade Air Lube 10W/NR (or equivalent) into the air inlet bushing of the tool while the throttle lever is depressed. Allowing the oil to flow into the air motor.
2. Release the throttle lever.
3. With the air supply valve in the **OFF** position, carefully connect the tool to the air supply hose. **Note:** Use a wrench to hold the air inlet bushing on the tool stationary when installing the air supply connection.
4. Once the tool is connected to the air supply, turn the supply valve to the **ON** position. Run the tool and use a tachometer to verify the rated operating speed (RPM) of the tool. The tool should operate within 5% of the maximum rated RPM. The tool RPM must never exceed the maximum rated RPM with the operating air supply pressure reading 90 PSIG (6.2 bar g) at the air inlet of the tool. To adjust free speed add or remove shims. Adding shims will increase the speed, removing shims will reduce the tool free speed. Once the correct rated operating speed for the tool is verified, disconnect the tool from the air supply and install the proper flanging and abrasive product.

Final Assembly Complete. Tool Assembly Complete.

Optional Accessories

FIND THE MOST CURRENT OFFERING OF SUPPORT DOCUMENTS AND ACCESSORIES @ WWW.DYNABRADE.COM



Dynabrade Angle Gear Oil

- Specifically formulated to saturate wick system in right angle gear head.

95848: 2.5 oz. tube

95541: Gear Oil Gun



96100 Motor Tune-Up Kit

- Includes assorted parts to help maintain and repair motor.

Machine Specifications

Model Number	Motor hp (W)	Motor RPM	Sound Level	Maximum Air Flow SCFM (LPM)	Spindle Thread	Air Pressure PSIG (Bars)	Weight Pound (kg)	Length Inch (mm)	Height Inch (mm)
5" Models	1.3 (969)	12,000	84 dB(A)	43 (1218)	5/8"-11	90 (6.2)	7 (3.2)	10-1/2 (267)	5-3/8 (136)
6" Models	1.3 (969)	12,000	84 dB(A)	43 (1218)	5/8"-11 or M14 x 2	90 (6.2)	7 (3.2)	10-3/4 (273)	5-3/8 (136)

Additional Specifications: Air Inlet Thread 3/8" NPT • Hose I.D. 3/8" (10mm)

Sound Level is the pressure measurement according to the method outlined in ISO regulation ISO-15744

Special Greasing Instructions



- Lubricate wick system through the angle gear oil fitting with 2-3 plunges for every 24 hours of use, to achieve maximum gear life. Prime pump to insure good oil flow.

Important: Use only the recommended angle gear oil for the wick system.

Do not contaminate the wick with any other oil or grease product. Insure that all 3 plunges of oil are injected through the fitting.

(Order **95848** Gear Oil and **95541** Gun)

Reference Contact Information

1. **American National Standards Institute – ANSI**
25 West 43rd Street
Forth Floor
New York, NY 10036
Tel: 1 (212) 642-4900
Fax: 1 (212) 398-0023
2. **Government Printing Office – GPO**
Superintendent of Documents
Attn. New Orders
P.O. Box 371954
Pittsburgh, PA 15250-7954
Tel: 1 (202) 512-1803
3. **Power Tool Institute, Inc.**
P.O. Box 818
Yachata, Oregon 97498-0818
Tel: 1 (503) 547-3185
Fax: 1 (503) 547-3539
4. **European Committee for Standardization**
Rue de Stassart 36
B - 1050 Brussels, Belgium

Visit Our Web Site: www.dynabrade.com

Email: Customer.Service@Dynabrade.com



DYNABRADE, INC., 8989 Sheridan Drive • Clarence, NY 14031-1419 • Phone: (716) 631-0100 • Fax: 716-631-2073 • International Fax: 716-631-2524
DYNABRADE EUROPE S.à.r.l., Zone Artisanale • L-5485 Wormeldange—Haut, Luxembourg • Telephone: 352 76 84 94 1 • Fax: 352 76 84 95 1

©DYNABRADE, INC., 2010

PRINTED IN USA