



## **0.4 hp. Right Angle Tools**

**Models:** 46000, 46001, 46002, 47800, 47801, 47802, 47820, 47821, 47822, 48315, 48316, 48317, 48520, 48521, 48522, 48540, 48541, 48542, 48530, 48531, 48532, 49425

Repair Tools:

96460 Wrench (Housing Core Nut)

96461 Repair Collar

96399 Special Repair Tool (Air Inlet & Internal Housing Hex)

50971 Lock Ring Tool

96346 Bearing Separator (2")

96232 Arbor Press (#2)

96239 Bearing Press Tool

96240 Bearing Press Tool

96242 Bearing Press Tool

*Visit Our Website:* [www.dynabrade.com](http://www.dynabrade.com)

*Email:* [customer.service@dynabrade.com](mailto:customer.service@dynabrade.com)

**DYNABRADE, INC. • DYNABRADE INTERNATIONAL**

8989 Sheridan Drive, Clarence, New York 14031-1490 USA  
Telephone: (716) 631-0100 • Fax: 716-631-2073 • Int'l Fax: 716-631-2524

**DYNABRADE DO BRASIL**

Rua Oneda, 632, Sao Bernardo do Campo • SP – CEP 09895-280  
Telephone: 55-11-4390-0133 • Fax: 55-11-4399-1067

**DYNABRADE EUROPE S.à.r.l.**

Zone Artisanale, L-5485 Wormeldange—Haut, Luxembourg  
Telephone: +352 768 494 1 • Fax: +352 768 495

**DYNABRADE INDIA ABRASIVE POWER TOOLS Pvt Ltd.**

EL-54, TTC Industrial Area, M.I.D.C. Mahape, Electronic Zone, Navi Mumbai - 400705  
Maharashtra, India • Telephone: +91 22 2763 2226 • Fax: +91 22 2763 2228