



Special Tools for Repair

1.0 hp. Straight Motor

Models: All

96232 Arbor Press (#2)

51989 Repair Collar

50971 Lock Ring Wrench

96209 Motor Collar

96346 Bearing Separator (2")

96211 Bearing Removal Tool

96243 Bearing Press Tool



Special Tools for Repair
