



Dynorbital Silver Supreme

Models: 69000, 69003, 69004, 69005, 69008, 69009, 69010, 69013, 69014, 69015, 69018, 69019, 69020, 69023, 69024, 69025, 69028, 69029, 69030, 69033, 69034, 69035, 69038, 69039, 69040, 69043, 69044, 69060, 69061, 69062, 69100, 69103, 69104, 69105, 69108, 69109, 69110, 69113, 69114

57098 – Motor Repair Kit

- Includes special tools for proper disassembly/assembly of Dynorbital Palm Sanders.

- **56056** Balancer Bearing Puller – Use to remove balancer (pad) bearing.
- **56058** Lock Ring Wrench – Use to loosen and tighten motor lock ring.
- **57091** Bearing Press Tool – Use to press balancer and motor bearings.
- **57092** Repair Collar – Use to hold/protect sander housing when secured in vise.
- **57099** Bearing Puller – Blind-Hole Puller use with 56056 Balancer Bearing Puller.
- **96034** 12 mm Hex Key – Use to install/remove exhaust and vacuum componets.
- **96066** 3/4" Thin-Wall Socket – Use to install/remove exhaust and vacuum componets.
(D3 Mdl.)

96346 – Bearing Separator (2")

96232 – Arbor Press (#2)

96239 – Bearing Press Tool

50679 – 26 mm Wrench

Visit Our Website: www.dynabrade.com

Email: customer.service@dynabrade.com

DYNABRADE, INC. • DYNABRADE INTERNATIONAL
8989 Sheridan Drive, Clarence, New York 14031-1490 USA
Telephone: (716) 631-0100 • Fax: 716-631-2073 • Int'l Fax: 716-631-2524

DYNABRADE DO BRASIL
Rua Oneda, 632, Sao Bernardo do Campo • SP – CEP 09895-280
Telephone: 55-11-4390-0133 • Fax: 55-11-4399-1067

DYNABRADE EUROPE S.à.r.l.
Zone Artisanale, L-5485 Wormeldange—Haut, Luxembourg
Telephone: +352 768 494 1 • Fax: +352 768 495

DYNABRADE INDIA ABRASIVE POWER TOOLS Pvt Ltd.
EL-54, TTC Industrial Area, M.I.D.C. Mahape, Electronic Zone, Navi Mumbai - 400705
Maharashtra, India • Telephone: +91 22 2763 2226 • Fax: +91 22 2763 2228