



Special Tools for Repair

0.4 hp. Router

Model: 51862

Repair Tools:

50971 Lock Ring Tool (BASE PLATE)

96232 Arbor Press (#2)

96242 Bearing Press Tool (02696 Bearing)

96346 Bearing Separator (2")

96399 Service Tool (Air Inlet)

96460 Service Tool (Exhaust Cover)