



Special Tools for Repair

Reversible, Pistol Grip Direct Drive Screwdriver

Models: 53472, 53474, 53475, 53477

96213 Bearing Removal Tool (02649 Bearing)

96214 Bearing Removal Tool (02651 Bearing)

96232 Arbor Press (#2)

96239 Bearing Press Tool (02651 Bearing)

96240 Bearing Press Tool (02649 Bearing)

96346 Bearing Separator (2")